

Data Values

IO-Link Data Map

This document refers to the following IODD file: Banner_Engineering-Q5X-JAM-20230315-IODD1.1.xml. The IODD file and support files can be found on www.bannerengineering.com under the download section of the product family page.

Parameter	Value	Parameter	Value
IO-Link revision	V1.1	Port class	Α
Process Data In length	32 bits	SIO mode	Yes
Process Data Out length	8 bits	Smart Sensor Profile	Yes
Bit Rate	38400 bps	Block parameterization	Yes
Minimum cycle time	3.6 ms	Data Storage	Yes
Device ID	0x090003		

Number of Bits

IO-Link Process Data In (Device to Master)

V_Configuration.10 = 0 => Process Data In

Subindex

1	Channel 1 C	Channel 1 Output State				0=inactive, 1=active	е		
2	Channel 2 C	Output State			1	0=inactive, 1=active			
3	Stability Sta	te			1	0=no target/margin	al, 1=stable		
4	Measureme	nt 1 Value			13	Value depends on Configuration.Measurem Selection			
5	Measureme	nt 2 Value			16	Value depends on Configuration.M	easurement 2 Se	election	
Octet 0									
Subindex	5	5	5	5	5	5	5	5	
Bit offset	31	30	29	28	27	26	25	24	
Value	0	0	0	0	0	0	1	0	
Octet 1									
Subindex	5	5	5	5	5	5	5	5	
Subindex									
Bit offset	23	22	21	20	19	18	17	16	

Value 1

Example based on the previous values:Channel 1 Output = Active

- Channel 2 Output = Inactive
- Stability State = Stable
- Measurement 1 Value = 8191
- Measurement 2 Value = 694



Subindex

Bit offset

Value

Octet 3
Subindex

Bit offset

V_Configuration.10 = 1 => Process Data In without Binary

Subindex		Name I			Numb	er of Bits	Data Values			
1	Measureme	Measurement 1 Value				Value depends on Configuration.Measuremen Selection				asurement 1
2	Measureme	nt 2 Value				16	Value Selec	e depends on Co ction	onfiguration.Mea	asurement 2
Octet 0										
Subindex	2	2	2	2	2	2		2	2	2
Bit offset	31	30	29	2	18	27		26	25	24
Value	0	0	0	(0	0		0	1	1
Octet 1										
Subindex	2	2	2	2	2	2		1	1	1
Bit offset	23	22	21	2	.0	19		18	17	16
Value	0	1	0	(0	1		0	1	1
Octet 2										
Subindex	1	1	1		1	1		1	1	1
Bit offset	15	14	13	1	2	11		10	9	8
Value	0	1	1	(0	0		1	1	1
Octet 3										
Subindex	1	1	1		1	1		1	1	1
Bit offset	7	6	5	4	4	3		2	1	0
Value	1	0	0	(0	1		1	1	1

Example based on the previous values:

- Measurement 1 Value = 26511
- Measurement 2 Value = 843

IO-Link Process Data Out (Master to Device)

Subindex		Name			per of Bits	Data Values			
1	Transducer [Fransducer Disable				0 = Active, 1 =	Inactive		
Octet 0									
Subindex	//	//	//	//	//	//		//	1
Bit offset	7	6	5	4	3	2		1	0
Value									1

Example based on the previous values:

• Transducer Disable = 1 (Inactive)

Parameters Set Using IO-Link

These parameters can be read from and/or written to an IO-Link model of the Q5X Jam Detection sensor. Also included is information about whether the variable in question is saved during Data Storage and whether the variable came from the IO-Link Smart Sensor Profile. Unlike Process Data In, which is transmitted from the IO-Link device to the IO-Link master cyclically, these parameters are read or written acyclically as needed.

Index	Subindex	Name	Length	Value Range	Default	Access Rights	Data Stor- age?	Smart Sen- sor Profile
0	1-16	Direct Parameter Page 1 (incl. Vendor ID & Device ID)				ro		

Continued on page 3

Index	Subindex	Name	Length	Value Range	Default	Access Rights	Data Stor- age?	Smart Sen
1	1-16	Direct Parameters Page 2				rw	ugo.	3011101110
2		Standard Command		65 = SP1 Single Value Teach; 67 = SP1 Two Value Teach TP1; 68 = SP1 Two Value Teach TP2; 71 = SP1 Dynamic Teach Start; 72 = SP1 Dynamic Teach Stop; 79 = SP1 Teach Exit; 130 = Restore Factory Settings; 160 = Laser Off; 161 = Laser On; 162 = Start discovery; 163 = Stop discovery		wo		у
3		Data Storage Index (device-specific list of parameters to be stored)				rw		
4-11		reserved by IO-Link Specification						
12		Device Access Locks						
12	1	Parameter Write Access Lock		0 = off 1 = on	0	rw	у	
12	2	Data Storage Lock		0 = off, 1 = on	0	rw	у	
12	3	Local Parameterization Lock		0 = off, 1 = on	0	rw	у	
12	4	Local User Interface Lock		0 = off, 1 = on	0	rw	у	
13		Profile Characteristic				ro		
14		PDInput Descriptor				ro		
15		PDOutput Descriptor				ro		
16		Vendor Name string		Banner Engineering Corporation		ro		
17		Vendor Text string		More Sensors. More Solutions.		ro		
18		Product Name string		Q5X		ro		
19		Product ID string		Q5XKLAF2000-Q8-JAM		ro		
20		Product Text string		Laser Measurement Sensor		ro		
21		Serial Number				ro		
22		Hardware Versopm				ro		
23		Firmware Version				ro		
24		App Specific Tag (user defined)				rw	у	
25		Function Tag				rw	у	
26		Location Tag				rw	у	
27-35		reserved						
36		Device Status	8-bit integer	0=Device is OK, 1=Maintainance required, 2=Out of specification, 3=Functional check, 4=Failure, 5-255 Reserved		ro		
37		Detailed Device Status	Array[6] of 3-octet			ro		
38-39		reserved						
40		Process Data Input		see Process Data In		ro		
41		Process Data Output		see Process Data Out		ro		
42-57		unused/reserved						
58		Teach-in Channel		0 = Default, 1 = BDC1, 2 = BDC2	0	rw		у
59		Teach-In Status						
59	1	Teach State	4-bit integer	0 = Idle, 1 = SP1 Success, 4 = Wait for Command, 5 = Busy, 7 = Error		ro		у
59	2	SP1 TP1	1-bit integer	0 = not taught or unsuccessful, 1 = successfully taught		ro		у
59	3	SP1 TP2	1-bit integer	0 = not taught or unsuccessful, 1 = successfully taught		ro		у
60		BDC1 Setpoints						
60	1	BDC1 Setpoint SP1	32-bit integer	95 mm2000 mm	2000 mm	rw	у	у
60	2	BDC1 Setpoint SP2 (FGS mode only)	32-bit integer	95 mm2000 mm	2000 mm	rw	у	у
61		BDC1 Configuration						
61	1	BDC1 Switchpoint Logic	8-bit integer	0 = Light Operate (LO), 1 = Dark Operate (DO)	0	rw	у	у

Continued on page 4

Continued from page 3

	Continued from page 3							
Index	Subindex	Name	Length	Value Range	Default	Access Rights	Data Stor- age?	Smart Sen- sor Profile
61	2	BDC1 Mode	8-bit integer	132 = Jam Retroreflective 133 = Jam Back- ground Suppression	132	rw	у	у
61	3	BDC1 Hysteresis	16-bit integer	0 mm	0 mm	rw	у	у
62		BDC2 Setpoints						
62	1	BDC2 Setpoint SP1	32-bit integer	95 mm2000 mm	2000 mm	rw	у	у
62	2	BDC2 Setpoint SP2 (FGS mode only)	32-bit integer	95 mm2000 mm	2000 mm	rw	у	у
63		BDC2 Configuration						
63	1	BDC2 Switchpoint Logic	8-bit integer	0 = LO, 1 = DO	0	rw	у	у
63	2	BDC2 Mode	8-bit integer	1 = One-Point BGS 128 = Two-Point static BGS, 129 = Dynamic BGS, 130 = One- Point Window (FGS), 131 = Dual Teach, 132 = Jam Retroreflective 133 = Jam Back- ground Suppression	133	rw	у	у
63	3	BDC2 Hysteresis	16-bit inte- ger	-2000 mm+2000 mm	0 mm	rw	у	у
64		Configuration						
64	1	Response Speed	8-bit Uinte- ger	2 = 15ms, 3 = 25ms, 4 = 50ms	4	rw	у	
64	2	Gain	8-bit Uinte- ger	0 = High excess gain mode; 1 = Standard excess gain mode	0	rw	у	
	3	Secondary Output Function	8-bit Uinte- ger	0 = Remote Teach Input; 1 = Laser On; 2 = Master; 3 = Slave; 4 = Complementary Output; 5 = Laser Off; 6 = Pulse Frequency Modulation; 7 = Independent Output	7	rw	у	
64	4	Zero Reference Location	8-bit Uinte- ger	0 = Near; 1 = Far	0	rw	у	
64	5	Shift Zero Reference After Teach	8-bit Uinte- ger	0=Off; 1=Off	0	rw	у	
64	6	Display Read	8-bit Uinte- ger	0 = On; 1 = On; Inverted; 2 = Off; 3 = Off; Inverted	0	rw	у	
64	7	Pushbutton Lockout	8-bit Uinte- ger	0 = No Lock-out; 1 = Pushbuttons Locked; 2 = Operator Lockout	0	rw	у	
64	8	Output Polarity	8-bit Uinte- ger	0 = Default; 1 = PNP; 2 = NPN	0	rw	у	
64	9	IOL Filter Time	16-bit Uinte- ger	065535	0	rw	у	
64	10	Include Binary Data in Process Data	8-bit Uinte- ger	0 = Include, 1 = Don't Include	0	rw	у	
64	11	Process Data Measurement 1 Selection	8-bit Uinte- ger	0 = Disabled, 1 = Excess Gain, 2 = Excess Gain / 10	1	rw	у	
64	12	Process Data Measurement 2 Selection	8-bit Uinte- ger	0 = Disabled, 1 = Distance Measurement Value, 2 = Displayed Distance Measure- ment Value, 3 = Channel 2 Dual Mode Per- cent	1	rw	у	
65		BDC1 Vendor Specific Configuration						
65	1	BDC1 Delay Mode	8-bit Uinte- ger	0 = Disabled, 1 = On-Off Delay, 2 = Oneshot, 3 = Totalizer	0	rw	у	
65	2	BDC1 Delay Time 1	32-bit Uinte- ger	090000	0ms	rw	у	
65	3	BDC1 Delay Time 2	32-bit Uinte- ger	090000	0ms	rw	у	
65	4	BDC1 BGS Teach Offset Mode	8-bit Uinte- ger	0 = Auto, 1 = User Selected	0	rw	у	
65	5	BDC1 FGS Window Size Mode	8-bit Uinte- ger	0 = Auto, 1 = User Selected	0	rw	у	
65	6	BDC1 User Teach Offset	32-bit inte- ger	-1910 mm+1910 mm	0mm	rw	у	
65	7	BDC1 FGS User Window Size	32-bit integer	1 mm1910 mm	1mm	rw	у	
65	8	BDC1 Teach Minimum Moving Range	32-bit inte- ger		0mm	rw	у	
			_	entinued on page 5				

Continued on page 5

Continued from page 4

Profess Submitted Submi		Continued from page 4							
Section Sect	Index	Subindex	Name	Length	Value Range	Default			Smart Sen- sor Profile
Second S	65	9				0ms	rw	у	
BOLD Delay Month	65	10			0 = On, 1 = Off, 2 = High Speed	1	rw	у	
Second Control Contr	66		BDCD Vendor Specific Configuration						
Second S	66	1	BDC2 Delay Mode			0	rw	у	
Second S	66	2	BDC2 Delay Time 1		090000	0ms	rw	у	
Second S	66	3	BDC2 Delay Time 2		090000	0ms	rw	у	
66	66	4	BDC2 BGS Teach Offset Mode		0 = Auto, 1 = User Selected	0	rw	у	
Section Sect	66	5	BDC2 FGS Window Size Mode		0 = Auto, 1 = User Selected	0	rw	у	
Second Communication Second Sec	66	6	BDC2 User Teach Offset		-1910 mm+1910 mm	0mm	rw	у	
Beautiful	66	7	BDC2 FGS User Window Size		1 mm1910 mm	1mm	rw	у	
1	66	8	BDC2 Teach Minimum Moving Range			0mm	rw	у	
Status	66	9				0ms	rw	у	
1 Measurement Distance: (distance in um) 32-bit integer	66	10			0 = On, 1 = Off, 2 = High Speed	1	rw	у	
1	67		Status						
Second Scale Seco	67	1	Measurement Distance: (distance in um)				ro		
Stationary Ger Control angel, Entanglamentum per Pears, Entanglamentum per Pears, Festatule Ger Ge	67	2	Excess Gain				ro		
Solution	67	3	Stability		0=No target, 1=Marginal/Multiple Peaks,	, 2=Stable	ro		
S	67	4	Multiple Peak State		0 = Multiple peaks not preset, 1 = Multiple p	eaks present	ro		
1	67	5	Emitter Status		0 = Active, 1 = Inactive		ro		
67 8 BDC2 Totalizer Counts 16-bit Uinteger 10 10 10 10 10 10 10 1	67	6	Laser Fault Status		0 = Not present, 1 = Laser fault pre	esent	ro		
69	67	7	BDC1 Totalizer Counts				ro		
69 1 Run counter 32-bit Uinteger ro ro 70 Resettable Run Time 0 nw ro 70 1 Run counter 32-bit Uinteger 0 nw 0 71 Pulse Frequency Configuration 0 nw y 0 71 1 Near Frequency 32-bit integer 100.45000 100Hz nw y 71 2 Far Frequency 32-bit integer 100.45000 600Hz nw y 72 Display String 1 ro ro ro 72 1 Line 1 5-octet String US_ASCII ro ro ro 76 All-Time Run Time Event Time 02147483647 0 nw y 77 Resettable Run Time Event Time 32-bit Uinteger 0.2147483647 0 nw y	67	8	BDC2 Totalizer Counts				ro		
1	69		All-Time Run Time						
70 1 Run counter 32-bit Uinteger 0 rw 9 71 Pulse Frequency Configuration 100.45000 100Hz rw y 71 1 Near Frequency 32-bit integer 100.45000 600Hz rw y 72 Display String 5-octet String US_ASCII ro ro ro 76 All-Time Run Time Event Time 32-bit Uinteger 0.2147483647 0 rw y 77 Resettable Run Time Event Time 32-bit Uinteger 0.2147483647 0 rw y	69	1	Run counter				ro		
The counter Ger Continue	70		Resettable Run Time						
71 1 Near Frequency 32-bit integer 100.45000 100Hz nw y 71 2 Far Frequency 32-bit integer 100.45000 600Hz nw y 72 Display String ro ro ro 72 1 Line 1 String US_ASCII ro ro 76 All-Time Run Time Event Time 32-bit Uinteger 02147483647 0 nw y 77 Resettable Run Time Event Time 32-bit Uinteger 02147483647 0 nw y	70	1	Run counter			0	rw		
100.45000 100.	71		Pulse Frequency Configuration						
72	71	1	Near Frequency		10045000	100Hz	rw	у	
72	71	2	Far Frequency		10045000	600Hz	rw	у	
72 1 Line 1 String US_ASCII ro 76 All-Time Run Time Event Time 32-bit Uinteger 0.2147483647 0 rw y 77 Resettable Run Time Event Time 32-bit Uinteger 0.2147483647 0 rw y	72		Display String						
76 1 Event Time 32-bit Uinteger 02147483647 0 rw y 77 Resettable Run Time Event Time 32-bit Uinteger 02147483647 0 rw y	72	1	Line 1	String			ro		
77 Resettable Run Time Event Time 32-bit Uinte-	76		All-Time Run Time Event Time						
77 1 Event Time 32-bit Uinte- 0. 2147483647 0 0 0 0 0	76	1	Event Time		02147483647	0	rw	у	
	77		Resettable Run Time Event Time						
	77	1	Event Time		02147483647	0	rw	у	

IO-Link Events

Events are acyclic transmissions from the IO-Link device to the IO-Link master. Events can be error messages and/or warning or maintenance data.

Code	Туре	Name	Description
25376 (0x6320)	Error	Parameter error	Check datasheet and values
36000 (0x8CA0)	Warning	All-time Run Time Event	Event indicating the corresponding configured running time has elapsed.
36001 (0x8CA1)	Warning	Resettable Run Time Event	Event indicating the corresponding configured running time has elapsed.
36003 (0x8CA3)	Notification	Teach Completed Event	Event indicating a teach has been completed.
36004 (0x8CA4)	Notification	Factory Settings Restored Event	Event indicating that the factory settings have been restored.
36005 (0x8CA5)	Notification	Teach Coerced Event	Event indicating a taught condition resulting in a setpoint being coerced. Taught was updated.
36007 (0x8CA7)	Notification	Teach Failed Event	Event indicating an invalid target condition was attempted to be taught. Taught setpoint was not updated.
36096 (0x8d00)	Error	Laser fault event	Indicate that the laser drive has been shut down due to a safety fault.
36097 (0x8D01)	Error	System Fault Event	Contact Banner Engineering to resolve.