Q5XKLAF5000 and 10000 IO-Link Data Reference Guide



IO-Link Data Map

This document refers to the following IODD file: Banner_Engineering-Q5XKLAF5000-20230418-IODD1.1.xml. The IODD file and support files can be found on www.bannerengineering.com under the download section of the product family page.

Communication Parameters

The following communication parameters are used.

Parameter	Value	Parameter	Value
IO-Link revision	V1.1	Port class	A
Process Data In length	32 bits	SIO Mode	Yes
Process Data Out length	8 bits	Smart sensor profile	Yes
Bit Rate	38400 bps	Block parameterization	Yes
Minimum cycle time	3.6 ms	Data Storage	Yes

IO-Link Process Data In (Device to Master)

Configuration: Include Binary in Process Data = Include

Process Data Input

Subindex	Name				Numbe	r of Bits	Data Values			
1	Channel 1 Output	State			1		0 = inac 1 = activ			
2	Channel 2 Output	State			,	l	0 = inactive 1 = active			
3	Stability State	Stability State				I	0 = no ta 1 = stab	arget/marginal (low le	excess gain)	
4	Measurement 1 Va	Measurement 1 Value				3	Value de	epends on "Configu	ıration.Measuremer	nt 1 Selection"
5	Measurement 2 Va	Measurement 2 Value			1	6	Value de	epends on "Configu	ıration.Measuremer	nt 2 Selection"
Octet 0										
Subindex	5	5	5	5		5		5	5	5
Bit offset	31	30	29	28		27		26	25	24
Value	0	0	0	0		0 0		0	1 0	
Octet 1										
Subindex	5	5	5	5		5		5	5	5
Bit offset	23	22	21	20		19		18	17	16
Value	1	0	1	1		0		1	1	0
Octet 2										
Subindex	4	4	4	4		4		4	4	4
Bit offset	15	14	13	12		11		10	9	8
Value	1	1	1	1		1		1	1	1
Octet 3										
Subindex	4	4 4 4		4		4		3	2	1
Bit offset	7	6	5	4		3		2	1	0
Value	1	1	1	1		1		1	0	1

Example Based on the Value Above

Channel 1 Output = Active



Channel 2 Output = Inactive

Stability State = Stable

Measurement 1 Value = 8191

Measurement 2 Value = 694

Configuration: Include Binary in Process Data = Don't Include

Process Data Input

Subindex		Name				Number of Bits		Data Values				
1	Measurement 1 V	/alue			16	16 Value depends on "Configuration.Mea			ration.Measuremen	asurement 1 Selection"		
2	Measurement 2 \	/alue			16	3	Value depends on "Configuration.Measurement 2 Selection"					
Octet 0												
Subindex	2	2	2	2		2		2	2	2		
Bit offset	31	30	29	28		27		26	25	24		
Value	0	0	0	0		0		0	1	1		
Octet 1												
Subindex	2	2	2	2		2		1	1	1		
Bit offset	23	22	21	20		19		18	17	16		
Value	0	1	0	0		1		0	1	1		
Octet 2												
Subindex	1	1	1	1		1		1	1	1		
Bit offset	15	14	13	12		11		10	9	8		
Value	0	1	1	0		0		1	1	1		
Octet 3												
Subindex	1	1	1	1		1		1	1	1		
Bit offset	7	6	5	4		3		2	1	0		
Value	1	0	0	0		1		1	1	1		

Example Based on the Value Above

Measurement 1 Value = 26511

Measurement 2 Value = 843

Configuration: Include Binary in Process Data = Measurement Device

Process Data Input

Subindex	Name	Number of Bits	Data Values
1 N	Measurement Value	16	The measurement device value
2 N	Measurement Scale	8	The measurement device scale
3 8	Stability State	1	0 = no target/marginal (low excess gain) 1 = stable
4	Channel 2 Output State	1	0 = inactive 1 = active
5 (Channel 1 Output State	1	0 = inactive 1 = active

Octet 0								
Subindex	1	1	1	1	1	1	1	1
Bit offset	31	30	29	28	27	26	25	24

	Continued from page 2												
Octet 0													
Value	0	0	0	0	0	0	0	0					
Octet 1													
Subindex	1	1	1	1	1	1	1	1					
Bit offset	23	22	21	20	19	18	17	16					
Value	0	1	1	0	1	1	0	1					
0.1.10													
Octet 2													
Subindex	2	2	2	2	2	2	2	2					
Bit offset	15	14	13	12	11	10	9	8					
Value	1	1	1	1	1	1	1	0					
Octet 3													
Subindex	//	//	//	//	//	3	4	5					
Bit offset	7	6	5	4	3	2	1	0					
Value	N/A	N/A	N/A	N/A	N/A	0	1	0					

Example Based on the Value Above

Measurement Value = 109

Measurement Scale = -2

Scaled Measurement Value = 1.09 m

Stability State = no target/marginal (low excess gain)

Channel 2 Output State = Active

Channel 1 Output State = Inactive

IO-Link Process Data Out (Master to Device)

Process Data Output

Subindex	Name	Number of Bits	Data Values
1	Laser Status	1	0 = Enabled 1 = Disabled

Octet 0								
Subindex	//	//	//	//	//	//	//	1
Bit offset	7	6	5	4	3	2	1	0
Value	N/A	1						

Example Based on the Value Above

Laser Status = 1 (Disabled)

Parameters Set Using IO-Link

These parameters can be read from and/or written to an IO-Link model of the Q5XLAF5000 and Q5XKLAF10000 sensor. Also included is information about whether the variable in question is saved during Data Storage and whether the variable came from the IO-Link Smart Sensor Profile.

Unlike Process Data In, which is transmitted from the IO-Link device to the IO-Link master cyclically, these parameters are read or written acyclically as needed.

Index	Sub-index	Name	Length	Value Range	Default	Access Rights	Data Storage?	Smart Sensor Profile?
0	1-16	Direct Parameter Page 1 (incl. Vendor ID & Device ID)			ro			
1	1-16	Direct Parameters Page 2				rw		

Backer B				Contin	ued from page 3				
Part	Index	Sub-index	Name	Length	Value Range	Default	Access Rights		Smart Sensor Profile?
	2				67 = SP1 Two Value Teach TP1 68 = SP1 Two Value Teach TP2 71 = SP1 Dynamic Teach Start 72 = SP1 Dynamic Teach Stop 79 = SP1 Teach Exit 130 = Restore Factory Settings 162 = Start discovery		wo		у
	3		Data Storage Index (device-specific list of parameters to be stored)				rw		
1	4-11		reserved by IO-Link Specification						
1	12		Device Access Locks						
1	12	1	Parameter Write Access Lock			0	rw	у	
1	12	2	Data Storage Lock			0	rw	у	
1	12	3	Local Parameterization Lock			0	rw	у	
14	12	4	Local User Interface Lock			0	rw	у	
15	13		Profile Characteristic				ro		
18	14		PDInput Descriptor				ro		
17	15		PDOutput Descriptor				ro		
Product Name string	16		Vendor Name string		Banner Engineering Corporation		ro		
Product ID string	17		Vendor Text string		More Sensors. More Solutions.		ro		
Product Tout string	18		Product Name string		Q5X		ro		
21 Serial Number	19		Product ID string				ro		
Hardware Version	20		Product Text string				ro		
23 Firmware Version	21		Serial Number				ro		
24	22		Hardware Version				ro		
Function Tag	23		Firmware Version				ro		
26			App Specific Tag (user defined)				rw	у	
27-35 reserved	25						rw	у	
Device Status	26		Location Tag				rw	у	
36	27-35		reserved						
38-39 reserved	36		Device Status	8-bit integer			ro		
Process Data Input	37		Detailed Device Status	Array[6] of 3-octet			ro		
41 Process Data Output see Process Data Out ro 42-57 unused/reserved 0 = Default 0 = De	38-39		reserved						
42-57	40		Process Data Input		see Process Data In		ro		
58 Teach-in Channel 0 = Default 1 = BDC1	41		Process Data Output		see Process Data Out		ro		
58 Teach-in Channel 1 = BDC1 2 0 nw 0 nw y 59 Teach-In Status 0 = Idle 1 s SP1 Success 4 s Number 4 = Walt for Command 5 = Busy 7 s Error 1 feach State 4-bit integer 0 = Idle 1 s SP1 Success 4 s Number 4 = Walt for Command 5 = Busy 7 s Error no y 59 2 SP1 TP1 1-bit integer 0 = not taught or unsuccessful 1 = successfully taught no y 59 3 SP1 TP2 1-bit integer 0 = not taught or unsuccessfull 1 = successfully taught no y 60 BDC1 Setpoints 5 - 0 - 10000 mm 250 mm nw y y	42-57		unused/reserved						
59 1 Teach State 4-bit integer 0 = Idle 1 = SP1 Success 4 = Vail for Command 5 = Busy 7 = Error ro y 59 2 SP1 TP1 1-bit integer 0 = not taught or unsuccessful 1 = successfully taught ro y 59 3 SP1 TP2 1-bit integer 0 = not taught or unsuccessful 1 = successfully taught ro y 60 BDC1 Setpoints ro y 60 1 BDC1 Setpoint SP1 32-bit integer 50-10000 mm 250 mm rw y y	58		Teach-in Channel		1 = BDC1	0	rw		у
59 1 Teach State 4-bit integer 1 = SP1 Success 4 = Walf for Command 5 = Busy 7 = Error ro y 59 2 SP1 TP1 1-bit integer 0 = not taught or unsuccessful 1 = successfully taught ro y 59 3 SP1 TP2 1-bit integer 0 = not taught or unsuccessful 1 = successfully taught ro y 60 BDC1 Setpoints 50 = 10000 mm 250 mm rw y	59		Teach-in Status						
59 2 SP1 TP1 1-bit integer 1 = successfully taught ro y 59 3 SP1 TP2 1-bit integer 0 = not taught or unsuccessfull 1 = successfully taught ro y 60 BDC1 Setpoints	59	1	Teach State	4-bit integer	1 = SP1 Success 4 = Wait for Command 5 = Busy		ro		у
59 3 SP1 TP2 1-bit integer 1 = successfully taught ro y 60 BDC1 Setpoints y y 60 1 BDC1 Setpoint SP1 32-bit integer 50-10000 mm 250 mm rw y y	59	2	SP1 TP1	1-bit integer			ro		у
60 1 BDC1 Setpoint SP1 32-bit integer 50–10000 mm 250 mm rw y	59	3	SP1 TP2	1-bit integer			ro		у
	60		BDC1 Setpoints						
60 2 BDC1 Setpoint SP2 (FGS mode only) 32-bit integer 50-10000 mm 0 mm rw y y	60	1	BDC1 Setpoint SP1	32-bit integer	50–10000 mm	250 mm	rw	у	у
	60	2	BDC1 Setpoint SP2 (FGS mode only)	32-bit integer	50–10000 mm	0 mm	rw	у	у

			Continu	ued from page 4				
Index	Sub-index	Name	Length	Value Range	Default	Access Rights	Data Storage?	Smart Sensor Profile?
61		BDC1 Configuration						
61	1	BDC1 Switchpoint Logic	8-bit integer	0 = LO 1 = DO	0	rw	у	у
61	2	BDC1 Mode	8-bit integer	1 = One-Point BGS; 128 = Two-Point static BGS; 129 = Dynamic BGS; 130 = One-Point Window (FGS); 131 = Dual Teach	128	rw	у	у
61	3	BDC1 Hysteresis	16-bit integer	-10000–10000 mm	0	rw	у	у
62		BDC2 Setpoints						
62	1	BDC2 Setpoint SP1	32-bit integer	50–10000 mm	500 mm	rw	у	у
62	2	BDC2 Setpoint SP2 (FGS mode only)	32-bit integer	50–10000 mm	0 mm	rw	у	у
63		BDC2 Configuration						
63	1	BDC2 Switchpoint Logic	8-bit integer	0 = LO; 1 = DO	0	rw	у	у
63	2	BDC2 Mode	8-bit integer	1 = One-Point BGS; 128 = Two-Point static BGS; 129 = Dynamic BGS; 130 = One-Point Window (FGS); 131 = Dual Teach	128	rw	у	у
63	3	BDC2 Hysteresis	16-bit integer	-10000 mm – 10000 mm	0	rw	у	у
64		Configuration						
				0 = 2 ms				
64	1	Response Speed	8-bit Uinteger	1 = 5 ms 2 = 15 ms 3 = 50 ms 4 = 250 ms	3	rw	у	
64	2	Gain	8-bit Uinteger	0 = Normal excess gain mode; 1 = Best accuracy excess gain mode; 2 = High excess gain mode	1	rw	у	
	3	Secondary Output Function	8-bit Uinteger	0 = Remote Teach Input; 1 = Laser On; 2 = Master; 3 = Slave; 4 = Complementary Output; 5 = Laser Off; 6 = Pulse Trequency Modulation; 7 = Independent Output	7	rw	у	
64	4	Zero Reference Location	8-bit Uinteger	0 = Near 1 = Far	0	rw	у	
64	5	Shift Zero Reference After Teach	8-bit Uinteger	0=Off 1=Off	0	rw	у	
64	6	Display Read	8-bit Uinteger	0 = On 1 = On + Inverted 2 = Off 3 = Off + Inverted	0	rw	у	
64	7	Display Units	8-bit Uinteger	0 = Centimeters 1 = Inches 2 = Millimeters	0	rw	у	
64	8	Pushbutton Lockout	8-bit Uinteger	0 = No Lock-out 1 = Pushbuttons Locked 2 = Operator Lockout	0	rw	У	
64	9	Output Polarity	8-bit Uinteger	0 = Default 1 = PNP 2 = NPN	0	rw	у	
64	10	IOL Filter Time (ms)	16-bit Uinteger	0-65535	0	rw	у	
64	11	Include Binary Data in Process Data	8-bit Uinteger	0 = Include 1 = Don't Include 2 = Measurement Device	0	rw	у	
64	12	Process Data Measurement 1 Selection	8-bit Uinteger	0 = Disabled 1 = Excess Gain 2 = Excess Gain / 10 3 = Channel 1 Dual Mode Percent	1	rw	у	
64	13	Process Data Measurement 2 Selection	8-bit Uinteger	0 = Disabled 1 = Distance Measurement Value (mm) 2 = Displayed Distance Measurement Value (mm)(1) 3 = Channel 2 Dual Mode Percent	1	rw	у	
65		BDC1 Vendor Specific Configuration						
65	1	BDC1 Delay Mode	8-bit Uinteger	0 = Disabled 1 = On-Off Delay 2 = Oneshot 3 = Totalizer	0	rw	у	
65	2	BDC1 Delay Time 1	32-bit Uinteger	0–90000 ms	0 ms	rw	у	
65	3	BDC1 Delay Time 2	32-bit Uinteger	0–90000 ms	0 ms	rw	у	
				nued on name 6				

⁽¹⁾ Displays Distance Measurement Value with adjustments made by Zero Reference Location and Shift Zero Reference After Teach

			Con	tinued from page 5				
Index	Sub-Index	Name	Length	Value Range	Default	Access Rights	Data Storage?	Smart Sensor Profile?
65	4	BDC1 BGS Teach Offset Mode	8-bit Uinteger	0 = Auto 1 = User Selected	0	rw	у	
65	5	BDC1 FGS Window Size Mode	8-bit Uinteger	0 = Auto 1 = User Selected	0	rw	у	
65	6	BDC1 User Teach Offset	32-bit integer	-4050 mm – 4050 mm	0 mm	rw	у	
65	7	BDC1 FGS User Window Size	32-bit integer	20 mm – 4050 mm	0 mm	rw	у	
65	8	BDC1 Auto-Thresholding	8-bit Uinteger	0 = On 1 = Off 2 = High Speed	1	rw	у	
66		BDCD Vendor Specific Configuration						
66	1	BDC2 Delay Mode	8-bit Uinteger	0 = Disabled 1 = On-Off Delay 2 = Oneshot 3 = Totalizer	0	rw	у	
66	2	BDC2 Delay Time 1	32-bit Uinteger	0–90000 ms	0 ms	rw	у	
66	3	BDC2 Delay Time 2	32-bit Uinteger	0–90000 ms	0 ms	rw	у	
66	4	BDC2 BGS Teach Offset Mode	8-bit Uinteger	0 = Auto 1 = User Selected	0	rw	у	
66	5	BDC2 FGS Window Size Mode	8-bit Uinteger	0 = Auto 1 = User Selected	0	rw	у	
66	6	BDC2 User Teach Offset	32-bit integer	-4050 mm – 4050 mm	0 mm	rw	у	
66	7	BDC2 FGS User Window Size	32-bit integer	20 mm – 4050 mm	0 mm	rw	у	
66	8	BDC2 Auto-Thresholding	8-bit Uinteger	0 = On 1 = Off 2 = High Speed	1	rw	у	
67		Status						
67	1	Measurement Distance: (distance in mm)	32-bit integer			ro		
67	2	Excess Gain	32-bit integer			ro		
67	3	Stability	8-bit Uinteger	0 = No target 1 = Marginal (low excess gain)/Multiple Peaks 2 = Stable		ro		
67	4	Emitter Status	8-bit Uinteger	0 = Active 1 = Inactive		ro		
67	5	Laser Fault Status	8-bit Uinteger	0 = Not Present 1 = Laser Fault Present		ro		
67	6	BDC1 Totalizer Counts	16-bit Uinteger			ro		
67	7	BDC2 Totalizer Counts	16-bit Uinteger			ro		
67	8	Temperature (in 0.1 °C)	16-bit integer			ro		
67	9	Last Taught Temperature (in 0.1 °C)	16-bit integer			ro		
68		unused/reserved						
69		All-Time Run Time						
69	1	Run counter (0.25 hr)	32-bit Uinteger			ro		
70		Resettable Run Time						
70	1	Run counter (0.25 hr)	32-bit Uinteger		0	rw		
71		Pulse Frequency Configuration						
71	1	Near Frequency	32-bit integer	100 Hz – 45000 Hz	100 Hz	rw	у	
71	2	Far Frequency	32-bit integer	100 Hz – 45000 Hz	600 Hz	rw	у	
72		Display String						
72	1	Line 1	5-octet String US_ASCII			ro		
76		All-Time Run Time Event Time						
76	1	Event Time (0.25 hr)	32-bit Uinteger	0-2147483647	0	rw	у	
77		Resettable Run Time Event Time						
77	1	Event Time (0.25 hr)	32-bit Uinteger	0-2147483647	0	rw	у	
78		Pulse Frequency Setpoints						
	1	Setpoint SP1	32-bit UInteger	Switch point 30-10000 mm	30 mm	rw	у	
	2	Setpoint SP2	32-bit UInteger	In One-Point Window (FGS) TEACH, SP2 defines the second switching point. In other TEACH modes, SP2 is unused and must be written to 0; 30-10000 mm	5000 mm	rw	у	
79		Pulse Frequency LOS Frequency						
				Frequency used to indicate Loss-of-Signal;				

Continued from page 6

Index	Sub-index	Name	Length	Value Range	Default	Access Rights	Data Storage?	Smart Sensor Profile?
165 12		MDC Descriptor		Measuring Data Channel Descriptor - Smart Sensor Profile 2nd Edition				
16512	1	Lower Limit	32-bit integer			ro		
16512	2	Upper Limit	32-bit integer			ro		
16512	3	Unit	16-bit uinteger	1010 = m		ro		
16512	4	Scale	8-bit integer	-2 = range shift of (10)-2		ro		

IO-Link Events

Events are acyclic transmissions from the IO-Link device to the IO-Link master. Events can be error messages and/or warning or maintenance data.

Code	Туре	Name	Description
25376 (0x6320)	Error	Parameter error	Check datasheet and values
36000 (0x8CA0)	Warning	All-time Run Time Event	Event indicating the corresponding configured running time has elapsed.
36001 (0x8CA1)	Warning	Resettable Run Time Event	Event indicating the corresponding configured running time has elapsed.
36003 (0x8CA3)	Notification	Teach Completed Event	Event indicating a teach has been completed.
36004 (0x8CA4)	Notification	Factory Settings Restored Event	Event indicating that the factory settings have been restored.
36005 (0x8CA5)	Notification	Teach Coerced Event	Event indicating a taught condition resulting in a setpoint being coerced. Taught was updated.
36007 (0x8CA7)	Notification	Teach Failed Event	Event indicating an invalid target condition was attempted to be taught. Taught setpoint was not updated.
36096 (0x8d00)	Error	Laser fault event	Indicate that the laser drive has been shut down due to a safety fault.
36097 (0x8D01)	Error	System Fault Event	Contact Banner Engineering to resolve.

Document title: Q5XKLAF5000 and Q5XKLAF10000 IO-Link Data Reference Guide Part number: 217157

Part number: 217157 Revision: C Original Instructions

© Banner Engineering Corp. All rights reserved.

