Checkout Procedures

Semi-Annual Checkout Procedure

Banner Engineering highly recommends performing the System checkouts as described. However, a Qualified Person (or team) should evaluate these generic recommendations considering their specific application and determine the appropriate frequency of checkouts. This will generally be determined by a risk assessment, such as the one contained in ANSI B11.0. The result of the risk assessment will drive the frequency and content of the periodic checkout procedures and must be followed.

Perform the procedure contained on this Semi-Annual Checkout card every six months following System installation, or whenever changes are made to the System (either a new configuration of the S4B or changes to the machine). Semi-Annual checkouts must be performed by a **Qualified Person** (as defined by OSHA and in the Safety Glossary of the manual). A copy of the checkout results should be kept on or near the machine: see OSHA 1910.217(e)(1).

The Instruction Manual is p/n 230287.

| Perform the following every six months following the system installation. | | | |
|---|----|--|--|
| | 1 | Examine the guarded machine to verify that it is of a type and design compatible with the S4B. Refer to the Instruction Manual for a list of misapplications. | |
| | 2 | Verify that the Safety Distance from the closest hazard point of the guarded machine to the defined area is not less than the calculated distance as determined in the Instruction Manual and indicated here: | |
| | 3 | Verify that: Access to any dangerous parts of the guarded machine is not possible from any direction not protected by the S4B, hard guarding, or supplemental safeguarding, and It is not possible for a person to stand between the safety light screen and the dangerous parts of the machine, or Supplemental safeguarding and hard guarding, as described by the appropriate safety standards, are in place and functioning properly in any space (between the safety light screen and any hazard) which is large enough to allow a person to stand undetected by the S4B. | |
| | 4 | If used, verify that: The reset switch, if used, is mounted outside the guarded area, out of reach of anyone inside the guarded area and The means of preventing inadvertent use (e.g., rings or guards) is in place. | |
| | 5 | Examine the electrical wiring connections between the S4B OSSD outputs and the guarded machine's control elements to verify that the wiring meets the requirements stated in the instruction manual. | |
| | 6 | Inspect the area near the defined area (including work pieces and the guarded machine) for reflective surfaces. (Reflective surfaces may cause System beams to reflect around a person in the light screen, preventing the person from being detected and not stopping the machine motion.) Remove the reflective surfaces as possible by relocating them, painting, masking, or roughening them. Remaining problem reflections will become apparent during step 10. | |
| | 7 | Apply power to the S4B. Ensure that power to the guarded machine is OFF. Remove all obstructions from the defined area. | |
| | 8 | Observe the status indicators on the receiver to determine System status: • Lockout: Status flashing red; Zone 1 or Zone 3 on red • Blocked: Status red; One or more Zone indicators red • Clear: Status green; All Zone indicators green | |
| | 9 | If in a Clear condition, go to step 10. If in a Lockout condition, refer to the Troubleshooting section of the instruction manual. A Blocked condition indicates that one or more of the beams is misaligned or interrupted. To correct this situation: Check carefully for any obstruction in the beam path. Check for contamination. Clean the emitter and receiver windows as required (see the manual). If the defined area is completely clear of obstructions, realign the emitter and receiver, as described in the manual. | |
| | 10 | After the Status indicator and all Zone indicators are green, perform the trip test (described on the Daily Checkout card) to verify proper System operation and to detect possible reflection problems. Image: the S4B System does not respond properly to the trip test, do not attempt to use the System. If this occurs, the System cannot be relied on to stop dangerous machine motion when a person or object enters the sensing field. Image: the S4B System cannot be relied on to stop dangerous machine motion when a person or object enters the sensing field. Image: the S4B System cannot be relied on to stop dangerous machine motion when a person or object enters the sensing field. Image: the S4B System cannot be relied on to stop dangerous machine motion when a person or object enters the sensing field. Image: the S4B System cannot be relied on to stop dangerous machine motion when a person or object enters the sensing field. Image: the S4B System cannot be relied on to stop dangerous machine motion when a person or object enters the sensing field. Image: test test test test test test test te | |
| | 11 | Apply power to the guarded machine and verify that the machine does not start up. Insert the test piece into the defined area and verify that it is not possible for the guarded machine to be put into motion while a beam is blocked. | |

| Perform the following every six months following the system installation. | | | | |
|---|----|---|--|--|
| | 12 | Initiate machine motion of the guarded machine and, while it is moving, insert the optional test piece into the defined area. Do not attempt to insert the test piece into the dangerous parts of the machine. Upon blocking any beam, the dangerous parts of the machine should come to a stop with no apparent delay. Upon removal of the test piece from the defined area, verify that the machine does not automatically restart, and that the initiation devices must be engaged to restart the machine. | | |
| | 13 | Remove electrical power to the S4B. All OSSD outputs should immediately turn off and should not be capable of turning on until power is re- applied. | | |
| | 14 | Test the machine stopping response time, using an instrument designed for that purpose, to verify that it is the same or less than the overall system response time specified by the machine manufacturer. (Banner's Applications Engineering Department can recommend a suitable instrument.) | | |
| | | Important: Do not continue operation until the entire checkout procedure is complete and all problems are corrected. | | |
| | 15 | If any decrease in machine braking ability has occurred, make the necessary clutch/brake repairs, readjust Safety Distance ("D _S " or "S") appropriately, record the new distance calculation on the appropriate Daily Checkout Procedure card and/or in the manual, and re-perform the Daily Checkout procedure. | | |
| | 16 | Examine and test the machine primary control elements (MPCEs) and any intermediary controls (such as interface modules) to verify that they are functioning correctly and are not in need of maintenance or replacement. | | |
| | 17 | Inspect the guarded machine to verify that no other mechanical or structural problems could prevent the machine from stopping or assuming an otherwise safe condition when signalled to do so by the S4B. | | |
| | 18 | Examine and inspect the machine controls and connections to the S4B to verify that no modifications have been made which adversely affect the System. | | |
| | | Important: Do not continue operation until the entire checkout procedure is complete and all problems are corrected. | | |

